

## **ZeroDT S-4**

Transient/Surge Protection for 4-wires (2 pair)

The ZeroDT S-4 is a solution for providing overvoltage transient (surge) protection for the power input and output signals for sensors/devices such as transmitters and ultrasonic flow meters. It consists of a Type 4X cast 413 aluminum enclosure designed for use in hazardous locations with a ZeroDT I/O-24 module mounted inside. The ZeroDT I/O-24 module utilizes state-of-the-art advanced semiconductor (SASD) technology to provide fast, non-degrading protection against surges and lightning induced transients. The module provides transient overvoltage protection for 2 pairs, or 4-wires with 1,200 Amps of 8/20 µs surge current protection for each line (each line is independently protected — it (each line) has its own surge protector).

The ZeroDT S-4 can be used as a 'conduit junction box' next to the sensor/device to be protected, and this 'conduit junction box' will provide the needed surge protection to ensure your equipment's survivability.



## ELECTRICAL SPECIFICATIONS

- **Response Time:** <5 nanoseconds.
- Configuration: Series connected, or pass-thru -- protects 2 pair or 4 wires.
- Nominal Operating Voltage: 24 VDC.
- Maximum Pass-thru Current (each line): 8 Amps.
- Maximum Continuous Operating Voltage (MCOV) Line-to-Ground: 36 VDC.
- Nominal Surge Current, I<sub>Nom</sub> (able to withstand repeated applications on each line):
  - ο 8/20 μs (IEEE/ANSI C62.41 Combination Wave), Line-to-Ground: >1,200 Amps.
    - ο 10/1000 μs (IEEE/ANSI C62.41 Long Wave), Line-to-Ground: >130 Amps.

### **O** MECHANICAL SPECIFICATIONS

- Power & Signal Input / Output Connections: Screw compression lug,
- Conductor Size: #26 to #14 AWG
- Enclosure Manufacturer/Catalog Number: Killark HKBX box and HKX2D dome cover
- Grounding/Earthing: Grounding terminal on exterior of enclosure.
- Enclosure Openings: Qty 3, 3/4" NPT

### **ENVIRONMENTAL SPECIFICATIONS**

- **Operating / Storage Temperature:** -40°C to +65°C.
- Humidity: 0 to 95% non-condensing.

## CERTIFICATIONS

- ZERODT I/O-24 Module mounted in the enclosure meets the requirements of:
  - Hazardous Locations -- Class I, Division 2, Groups A, B, C, D T6
  - Ordinary Locations UL 497B
  - Enclosure meets the requirements of:
  - Hazardous Locations -- Class I, Groups A, B, C, D;
    - Class I, Zone 1, AEx db IIC; Classs II, Groups E, F, G
      - Class III


(See manufacture spec. sheet for additional information)





# ZeroDT S-4

Transient/Surge Protection for 4-wires (2 pair)



#### ▲ WARNING EXPLOSION HAZARD: Do not disconnect equipment while the circuit is live or unless the area is known to be free of ignitable concentrations.



A ZeroDT S-4 surge protection junction box providing protection for equipment.

## **INSTALLATION PROCEDURE**

#### ENCLOSURE / HOUSING MUST BE PROPERLY BONDED TO A LOW RESISTANCE EARTH/GROUND FOR PROPER OPERATION AND OVERVOLTAGE PROTECTION !

- 1. For maximum overvoltage protection, mount the ZeroDT S-4 as close as possible to the device/equipment to be protected.
- 2. The ZeroDT S-4 unit is to be installed in accordance with the applicable requirements of the National Electric Code and the local authorities having jurisdiction.
- **3.** Install the Earth/Ground connection using the Green Grounding Screw on the flange of the enclosure/housing. The unit MUST BE PROPERLY BONDED TO A LOW RESISTANCE EARTH/GROUND FOR PROPER OVERVOLTAGE PROTECTION
- **4.** Wiring Installation: Terminate either DC power or data/signal loop conductors to the screw terminals provided on the module according to the legend. NOTE: screw terminals are compatible with #14 -#26 AWG, stripping length 5/16" (8 mm), and tighten to 4.5-to-5.5-inch pounds (0.5 to 0.6 Nm).

The ZeroDT I/O-24 allows either side of the module to be the Input or the Output (module orientation does not matter). Also, any path through the ZeroDT I/O-24 module can be used for DC power, pulse output signals, analog / 4-20 mA signals, or digital communications.

- 5. Repeat Step 4 for all the other conductors/lines passing through the ZeroDT S-4.
- 6. Fit the enclosure/housing cover and tighten securely.